



DESIGNER KEYBOARD

48 - Win - Keymap




Layer: 0

- B Spc Lower: Tap for Back Space, Hold for Layer Lower
- Del Raise: Tap for Delete, Hold for Layer Lower
- Adjust: Hold Lower and Raise to Adjust layer




Layer: 1 / Lower



Layer: 2 / Raise

- Mouse Scroll Down: Mouse Keys
- M(101): Macros
- M(201): Macros - Send Strip



Layer: 3 / Adjust

Hold Layer 1 & 2 to switch to Adjust

- BLE SEL: BLE mode
- USB SEL: USB mode
- Connect BLE 0: Connect BLE device 0
- Reset BLE 0: Reset BLE device 0
- Battery Level: Check Battery Level
- Deep Sleep: Deep Sleep mode for save battery
- DFU: DFU mode for flash firmware
- Reset All: Reset all BLE devices 0-4